

This quick-start guide will help you to start using your multi-ion straight away

Bluetooth probe user guide:

1. Download cleangrow app from the app store
2. Turn on the probe by pressing the button
3. Go to the 4th tab. Connect or reconnect the probe to your device
4. Select your solution set e.g. S3mg
5. Go to the first tab
6. If it's your first use or after sometime you will not be able to calibrate until you press condition.
7. For conditioning, calibrating and sampling follow the on screen guide
8. When finished DO NOT FORGET to power off the probe before putting it away.

Note: When moving from one solution to the next, dry the outer body of the probe.
Be gentle with it

Do NOT touch the tip of the probe

Support details

If you need further assistance or would like to purchase additional probes or calibration solutions, please e-mail us on sales@cleangrow.com or visit www.cleangrow.com

You can view all of our user manuals and documentation at:

<http://www.cleangrow.com>